

**Important: Always disconnect the power before installing or replacing bulbs and before cleaning or other maintenance.**

**To be installed by a licensed electrician**

1. Shut off power to the outlet box.
2. Attach the universal mounting plate to the outlet box using outlet box screws.
3. Make appropriate electrical connections using wire nuts. If there is no green ground wire from the outlet box, then connect the fixture wire to the mounting plate with the green screw provided. Place connections in outlet box.
4. Attach canopy over outlet box with canopy nuts

**Assembly Instructions**

5. Insert A-19 bulbs.
6. Place glass sheet inside fixture shell (frost side down toward room) and secure by bending the three clips by hand.
7. Attach the metal ring to the fixture shell with the six screws provided.
8. Set the fixture shell into the canopy, locating the mounting studs in holes and twist tight.

