

February 05, 2015

# Assembly Instructions

3190, 3191

## INSTRUCTIONS D'INSTALLATION

Cloche Series - Short Pendant, Long Pendant

### Important

- **Always disconnect the power before installing or replacing bulbs and before cleaning or other maintenance.**
- **Consult a qualified, licensed electrician to ensure correct branch circuit conductor.**  
*Consulter un électricien qualifié pour vous assurer que les conducteurs de la dérivation sont adéquats.*

1. Shut off power to the outlet box. (A)
2. Determine the height at which the fixture is to be hung.  
Use the Allen key (B) to loosen the set screw (C). Adjust the cord (D) to the desired length. Tighten the set screw to set. If necessary, cut cord to length plus six inches.
3. Adjust the cord lock (E) so it is 1" from the canopy to prevent slippage.
4. Place threaded socket (F) through the hole on metal washer 1 (G), glass (H) and metal washer 2 (I), secure with socket ring (J).
5. Install 60w medium base bulb (K). (not included).
6. Attach the universal mounting plate (L) to the outlet box, secure with outlet box screws (M).
7. Make appropriate electrical connections using wire nuts:
  - a. Connect the fixture's live wire (black) to the live outlet box wire.
  - b. Connect the fixture's neutral wire (white) to the neutral outlet box wire.
  - c. Connect the fixture's ground wire (green or uncoated) to the ground outlet box wire.
  - d. Carefully place connections in the outlet box (A).
8. Attach canopy (N) to universal mounting plate (L), secure with cap nut (O).
9. Restore power to the fixture.

### Care Instructions

- **Dusting: Use a clean, dry cloth.**
- **Cleaning: To protect the finish, avoid any harsh abrasives or chemicals.**

