SONNEMAN
A WAY OF LIGHT

Important: Always disconnect the power before installing or replacing bulb and before cleaning or other maintenance.

This light should be installed by a licensed electrician

LAMP INSTALLATION AND ASSEMBLY
1. Shut off power to the outlet box. (fig. A)
2. Attach the universal mounting plate to the outlet box, secure with outlet box screws.
3. Determine the height at which the fixture is to be hung. Unscrew the cord lock screw, set the adjustable cord to the desired length and, if necessary, cut cord to length plus six inches. Tighten the cord lock screw by screw driver to prevent slippage.
4. Place metal ring around inner glass. Screw the connectors to the glass bracket through the holes in the metal ring and inner glass.
5. Line up the holes of connectors and outer glass, secure with silicone washers and thumb screws.
6. Install 100W medium base bulb. (not included)
7. Make appropriate electrical connections using wire nuts:
   a. Connect the fixture's live wire (black) to the live outlet box wire.
   b. Connect the fixture's neutral wire (white) to the neutral outlet box wire.
   c. Connect fixture's ground wire (green or uncoated) to the ground outlet box wire. If no ground is present in outlet box, connect fixture's ground wire to the mounting plate using the green screw (included).
   d. Carefully place connections in outlet box.
8. Attach canopy to mounting plate, secure with canopy nuts.
9. Restore power to the fixture.

CARE INSTRUCTIONS
Dusting – Use a clean, dry cloth.
Cleaning – To protect the finish,
avoid any harsh abrasives or chemicals.